



## Activate Advance Features on SPOTER AXA Device

1. Add Admin number : #admin#123456#cell phone number#
2. Delete Admin number : #noadmin#123456#cell phone number#
  
3. SMS tracking : #smslink#123456#
  
4. GEO Fence SETUP : #stockade#123456#3#
  
5. Cancel GEO Fence Alert : #nostockade#123456#
  
6. Set Overspeed alarm : #speed#123456#060#
  
7. Cancel Overspeed alarm : #nospeed#123456#
  
8. Set ACC ON alarm : #ACC#ON#
  
9. Cancel ACC ON alarm : #ACC#OFF#
  
11. Cut Oil : #stopoil#123456#
  
12. Cut Electric : #stopelec#123456#
  
13. Supply Oil : # Supplyoil#123456#
  
14. Supply Electric : # Supplyelec#123456#

15. Power Failure Alarm :

Built-in backup battery to realize power failure alarm, it will send SMS "cut power alert!" to the authorized number.

-----