



Basic Installation of SPOTER – Silver DEVIce

1. Hardware Installation [wiring]:

There are four wires in **Device**:

- **Red wire connect to Battery POSITIVE [+] Pole.**
- **Black wire connect to Battery NEGATIVE [-] Pole.**
- **White wire connects to white wire [85] of RELAY.**
- **The Other wire connects to ACC / IGNITION Point.**

[Wrong ACC / IGNITION point connection may Burn the Device, Which make device out of warrantee.]

There are four wires in **RELAY**:

- **White wire [85] connects to white wire of Device.**
- **Yellow wire [86] wire connect to Battery POSITIVE [+] Pole.**
- **Green wire-1 [30] wire connects to power source side.**
- **Green wire-2 [87a] wire connects to Oil pump / main power / pump power side.**

The main Function of **RELAY** is connection and disconnection with **Green wire-1 [30] & Green wire-2 [87a]**
Put the device in a safe place, **much electric wiring area, meter box can block satellite signal.**

2. Software Installation [By SMS]:

The device configure via SMS command.

- **Activate the device in SERVER1 , SMS : 803#23.226.141.151#5002#**

Reply from Device SIM: **set ip ok / admin ip ok / OK**

- **Activate SIM APN SMS : For Vodafone : 802#www#**
For Airtel : : 802#airtelgprs.com#

Reply from Device SIM : **ok**

- **Restart The Device SMS : 930#**

Reply from Device SIM : **Restart ok / Ok**

3. Check Installation :

Login **SERVER1** and click on IMEI no of the Device , the device shows exact current location.

- **Check Device current setting SMS : 886#**

Reply from Device SIM : **Device IMEI , Server IP, Port, Apn Details.**

- **Power cut / Fuel off SMS from Owner mobile : 222#**
- **Power cut / Fuel On SMS from Owner mobile : 333#**

The Power cut / Fuel cut option will work after activating the service from company with owner mobile number.

4. General Fault Recovery :

If the device not shown in server properly, or show something different :

- **Check the FUSE in red wire.**
- **First Power off the device, Then Power on the Device after 5 minutes.**
- **Sent restart command through SMS : 930#**

After that the fault is not recovered you can do Factory reset by SMS : **940#**

Reply from Device SIM : **Ok / Factory reset Done.**

The Factory Setting commend will work after activating the service from company.

******* After Factory Setting you have do Software Installation [By SMS] Again.**